

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0401-001110	D6001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001561	ZD5002,ZD5003,ZD5004	DIODE-TVS
0406-001561	ZD6014	DIODE-TVS
0406-001592	ZD5007	DIODE-TVS
0406-001694	D5001	DIODE-TVS
0406-001728	ZD1000	DIODE-TVS
0406-001743	ZD6013	DIODE-TVS
0406-001781	ZD6015,ZD6016	DIODE-TVS
0406-001809	ZD5005,ZD5006	DIODE-TVS
0406-001829	ZD5014,ZD7000	DIODE-TVS
0505-002088	Q7000	FET-SILICON
0505-003618	Q5000	FET-SILICON
0601-003768	LED5001	LED
1001-002050	U3003	IC
1001-002063	U1000,U1001	IC
1001-002065	U1003,U2001,U2008	IC
1001-002065	U3019	IC
1001-002077	U2007,U2010	IC
1001-002078	U2004	IC
1003-002802	U2006	IC
1105-002962	UCP400UP	IC-FLASH
1107-002552	UME5000	IC-FLASH
1201-003869	U3008	IC
1201-004109	PAM1001	IC
1201-004135	PAM1000	IC
1201-004219	U1004,U1005,U2002	IC
1201-004219	U2009	IC
1201-004230	U1006,U2005	IC
1201-004245	U6001	IC
1203-008249	U3007,U3013	IC
1203-008251	U6000	IC
1203-008326	U3001	IC
1203-008475	U5010	IC
1203-008693	U2000	IC
1203-008859	U7003,U7006	IC
1203-008867	U3000,U7001	IC
1203-008870	U7007	IC

5. MAIN Electrical Parts List

1203-008925	U3010	IC
1203-008989	U7004,U7005	IC
1203-009213	U5000	IC
1203-009244	U7017	IC
1203-009258	U5002	IC
1205-005791	U3005	IC
1205-005860	U3004	IC
1205-005946	U2003	IC
1205-006117	UCP400	IC
1209-002428	U3017	IC
1209-002450	U3002	IC
1209-002621	U3006	IC
1404-001724	TH1000,TH4000,TH4001	THERMISTOR
1404-001724	VR5000	THERMISTOR
1405-001458	VR7000	VARISTOR
2007-003015	R5028,R5030	R-CHIP
2007-007190	R7064,R7065	R-CHIP
2007-007314	R3004,R3011	R-CHIP
2007-007317	R3010	R-CHIP
2007-007741	R2006,R3001,R4015	R-CHIP
2007-007741	R4021,R4049,R5019	R-CHIP
2007-007741	R5020,R5021,R5023	R-CHIP
2007-007741	R6019,R7005	R-CHIP
2007-007798	R5027	R-CHIP
2007-007942	R5011	R-CHIP
2007-007946	R5008	R-CHIP
2007-008531	R7002,R7044,R7061	R-CHIP
2007-008588	R3012,R3013	R-CHIP
2007-008800	R6012	R-CHIP
2007-009111	R3014,R7052	R-CHIP
2007-009157	R1005,R3000,R4000	R-CHIP
2007-009157	R4001,R4002,R4010	R-CHIP
2007-009157	R4047,R5001,R5010	R-CHIP
2007-009157	R6005,R6008	R-CHIP
2007-009171	R5007,R5013	R-CHIP
2007-009212	R4003,R4035,R5012	R-CHIP
2007-009212	R5018,R6006	R-CHIP
2007-009315	R7063	R-CHIP
2007-009352	R7011,R7047	R-CHIP

5. MAIN Electrical Parts List

2007-009408	R4006,R4008,R4018	R-CHIP
2007-009408	R4022,R4023,R4024	R-CHIP
2007-009408	R4027,R4029,R4030	R-CHIP
2007-009408	R4031,R4041,R4042	R-CHIP
2007-009408	R5015,R5024,R5025	R-CHIP
2007-009408	R6007,R7003,R7004	R-CHIP
2007-009408	R7042,R7043	R-CHIP
2007-009410	R6014	R-CHIP
2007-009766	R3002	R-CHIP
2007-009793	R6013	R-CHIP
2007-009801	R5000	R-CHIP
2007-009805	R1002,R1003,R2002	R-CHIP
2007-009920	R4004,R4005,R7050	R-CHIP
2007-009920	R7051	R-CHIP
2007-009969	R7062	R-CHIP
2007-010202	R5016,R5017	R-CHIP
2007-010685	R6010	R-CHIP
2007-010690	R3008	R-CHIP
2007-010691	R3009	R-CHIP
2007-011043	R4007,R4009,R4012	R-CHIP
2007-011043	R4050,R7049	R-CHIP
2007-011532	R6009	R-CHIP
2007-011648	R6003	R-CHIP
2007-011991	R3006	R-CHIP
2007-012068	R5009	R-CHIP
2007-012416	R3003	R-CHIP
2007-012417	R3005	R-CHIP
2203-000233	C7023	C-CERAMIC,CHIP
2203-000489	C5122,C5123	C-CERAMIC,CHIP
2203-000995	C5113	C-CERAMIC,CHIP
2203-001072	C3054	C-CERAMIC,CHIP
2203-001153	C3040,C3052	C-CERAMIC,CHIP
2203-005053	C3045	C-CERAMIC,CHIP
2203-005344	C5068	C-CERAMIC,CHIP
2203-005682	C5109,C5110,C5114	C-CERAMIC,CHIP
2203-005682	C5115,C8180,C8181	C-CERAMIC,CHIP
2203-005725	C3067	C-CERAMIC,CHIP
2203-005727	C3062,C3063	C-CERAMIC,CHIP
2203-005729	C6005,C6009,C7037	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005731	C2040,C6016,C6030	C-CERAMIC,CHIP
2203-005731	C6039,C6040,C8250	C-CERAMIC,CHIP
2203-005731	C8251	C-CERAMIC,CHIP
2203-005732	C5061	C-CERAMIC,CHIP
2203-005734	C6017,C6022,C6029	C-CERAMIC,CHIP
2203-005734	C8248	C-CERAMIC,CHIP
2203-005736	C1001,C1005,C1007	C-CERAMIC,CHIP
2203-005736	C1014,C1015,C1019	C-CERAMIC,CHIP
2203-005736	C1022,C1026,C1033	C-CERAMIC,CHIP
2203-005736	C1039,C1040,C1042	C-CERAMIC,CHIP
2203-005736	C1048,C1054,C1058	C-CERAMIC,CHIP
2203-005736	C1062,C1064,C1066	C-CERAMIC,CHIP
2203-005736	C1067,C1068,C1070	C-CERAMIC,CHIP
2203-005736	C1071,C1074,C1079	C-CERAMIC,CHIP
2203-005736	C1091,C1102,C1103	C-CERAMIC,CHIP
2203-005736	C1119,C1128,C2000	C-CERAMIC,CHIP
2203-005736	C2017,C2019,C2024	C-CERAMIC,CHIP
2203-005736	C2025,C2037,C2055	C-CERAMIC,CHIP
2203-005736	C2059,C2060,C2062	C-CERAMIC,CHIP
2203-005736	C2063,C2064,C2065	C-CERAMIC,CHIP
2203-005736	C2067,C2068,C2070	C-CERAMIC,CHIP
2203-005736	C2073,C3001,C3008	C-CERAMIC,CHIP
2203-005736	C3011,C3035,C3060	C-CERAMIC,CHIP
2203-005736	L1006,L1010,L2024	C-CERAMIC,CHIP
2203-005736	L3001	C-CERAMIC,CHIP
2203-005777	C1018,C1020,C1030	C-CERAMIC,CHIP
2203-005777	C1049,C1078,C1083	C-CERAMIC,CHIP
2203-005777	C1089,C1107,C3004	C-CERAMIC,CHIP
2203-005777	C3014,C3027,L1003	C-CERAMIC,CHIP
2203-005789	C1029,C1044,C1073	C-CERAMIC,CHIP
2203-005789	C1077,C1081,C1087	C-CERAMIC,CHIP
2203-005789	C1094,C1108	C-CERAMIC,CHIP
2203-005792	C1050,C1053,C1055	C-CERAMIC,CHIP
2203-005792	C1059,C1075,C3097	C-CERAMIC,CHIP
2203-005792	C6002	C-CERAMIC,CHIP
2203-005806	C3029	C-CERAMIC,CHIP
2203-006194	C6020,C6027	C-CERAMIC,CHIP
2203-006260	C7003	C-CERAMIC,CHIP
2203-006318	C1072,C6035	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006400	C2032,C2045,C2083	C-CERAMIC,CHIP
2203-006400	C3033,C3038,C3048	C-CERAMIC,CHIP
2203-006400	C3049,C6003,C6007	C-CERAMIC,CHIP
2203-006410	C3016,L1038	C-CERAMIC,CHIP
2203-006423	C2028,C2049,C2058	C-CERAMIC,CHIP
2203-006423	C3031,C3059,C3064	C-CERAMIC,CHIP
2203-006423	C3065,C3100,C4005	C-CERAMIC,CHIP
2203-006423	C4012,C4013,C6019	C-CERAMIC,CHIP
2203-006423	C8178,C8179,C8255	C-CERAMIC,CHIP
2203-006556	C5045,C5090	C-CERAMIC,CHIP
2203-006604	C3028	C-CERAMIC,CHIP
2203-006611	C1056,C3015,C3037	C-CERAMIC,CHIP
2203-006642	C6004,C6032	C-CERAMIC,CHIP
2203-006648	C8249	C-CERAMIC,CHIP
2203-006665	C1076,L2022	C-CERAMIC,CHIP
2203-006668	C4064,C6041	C-CERAMIC,CHIP
2203-006674	C1052	C-CERAMIC,CHIP
2203-006707	C1125	C-CERAMIC,CHIP
2203-006839	C1023,C1045,C2007	C-CERAMIC,CHIP
2203-006839	C2009,C2015,C2022	C-CERAMIC,CHIP
2203-006839	C2023,C2043,C2046	C-CERAMIC,CHIP
2203-006839	C2047,C2051,C2066	C-CERAMIC,CHIP
2203-006839	C4035,C5092,C5167	C-CERAMIC,CHIP
2203-006839	C7031	C-CERAMIC,CHIP
2203-006846	C4032,U10870,U4003	C-CERAMIC,CHIP
2203-006846	U4004	C-CERAMIC,CHIP
2203-007143	C5057	C-CERAMIC,CHIP
2203-007194	C1101,C3044,C3051	C-CERAMIC,CHIP
2203-007194	C7004	C-CERAMIC,CHIP
2203-007210	C4025,C4050,C4051	C-CERAMIC,CHIP
2203-007210	C4068,C4087,C4094	C-CERAMIC,CHIP
2203-007210	C4101,C5067,C5078	C-CERAMIC,CHIP
2203-007210	C5117,U10889	C-CERAMIC,CHIP
2203-007270	C7147	C-CERAMIC,CHIP
2203-007271	C5042,C5168	C-CERAMIC,CHIP
2203-007317	C2088,C3020,C3058	C-CERAMIC,CHIP
2203-007317	C4011,C4023,C4024	C-CERAMIC,CHIP
2203-007317	C4039,C4074,C4078	C-CERAMIC,CHIP
2203-007317	C5032,C5034,C5035	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007317	C5036,C5116,C6000	C-CERAMIC,CHIP
2203-007391	C2001,C2005,C2034	C-CERAMIC,CHIP
2203-007391	C2036	C-CERAMIC,CHIP
2203-007392	C5172	C-CERAMIC,CHIP
2203-007393	C2012,C5072,C5084	C-CERAMIC,CHIP
2203-007393	C5095,C5096,C5097	C-CERAMIC,CHIP
2203-007393	C5099,C5118,C5194	C-CERAMIC,CHIP
2203-007393	C7039,C8177	C-CERAMIC,CHIP
2203-007403	C1025	C-CERAMIC,CHIP
2203-007456	C5077,C5112	C-CERAMIC,CHIP
2203-007474	C4047,C4049,C4069	C-CERAMIC,CHIP
2203-007474	C5056	C-CERAMIC,CHIP
2203-007796	C2008,C2010,C2011	C-CERAMIC,CHIP
2203-007796	C2016,C2021,C2029	C-CERAMIC,CHIP
2203-007796	C2048,C2050,C2052	C-CERAMIC,CHIP
2203-007796	C3000,C3002,C3005	C-CERAMIC,CHIP
2203-007796	C3007,C3017,C3018	C-CERAMIC,CHIP
2203-007796	C3019,C3022,C3025	C-CERAMIC,CHIP
2203-007796	C3030,C3047,C3057	C-CERAMIC,CHIP
2203-007796	C3073,C3081,C4002	C-CERAMIC,CHIP
2203-007796	C4004,C4006,C4007	C-CERAMIC,CHIP
2203-007796	C4008,C4009,C4010	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4018	C-CERAMIC,CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC,CHIP
2203-007796	C4022,C4026,C4029	C-CERAMIC,CHIP
2203-007796	C4030,C4033,C4034	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4045	C-CERAMIC,CHIP
2203-007796	C4053,C4054,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4062,C4063	C-CERAMIC,CHIP
2203-007796	C4065,C4066,C4067	C-CERAMIC,CHIP
2203-007796	C4071,C4072,C4073	C-CERAMIC,CHIP
2203-007796	C4075,C4076,C4077	C-CERAMIC,CHIP
2203-007796	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007796	C4082,C4083,C4088	C-CERAMIC,CHIP
2203-007796	C4089,C4090,C4091	C-CERAMIC,CHIP
2203-007796	C4092,C4093,C5001	C-CERAMIC,CHIP
2203-007796	C5005,C5006,C5008	C-CERAMIC,CHIP
2203-007796	C5009,C5012,C5013	C-CERAMIC,CHIP
2203-007796	C5014,C5015,C5016	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C5017,C5018,C5019	C-CERAMIC,CHIP
2203-007796	C5020,C5024,C5025	C-CERAMIC,CHIP
2203-007796	C5026,C5029,C5030	C-CERAMIC,CHIP
2203-007796	C5073,C5085,C5088	C-CERAMIC,CHIP
2203-007796	C5100,C5101,C5102	C-CERAMIC,CHIP
2203-007796	C5104,C5107,C5108	C-CERAMIC,CHIP
2203-007796	C5120,C5178,C6033	C-CERAMIC,CHIP
2203-007796	C7001,C7005,C7011	C-CERAMIC,CHIP
2203-007796	C7012,C7013,C7014	C-CERAMIC,CHIP
2203-007796	C7018,C7019,C7022	C-CERAMIC,CHIP
2203-007796	C7024,C7033,C7041	C-CERAMIC,CHIP
2203-008097	C6010,C6042	C-CERAMIC,CHIP
2203-008158	C5153	C-CERAMIC,CHIP
2203-008242	C2089,C3023,C3042	C-CERAMIC,CHIP
2203-008242	C4001,C4003,C4017	C-CERAMIC,CHIP
2203-008242	C4043,C4044,C5000	C-CERAMIC,CHIP
2203-008242	C5002,C5004,C5007	C-CERAMIC,CHIP
2203-008242	C5010,C5011,C5021	C-CERAMIC,CHIP
2203-008242	C5022,C5023,C5027	C-CERAMIC,CHIP
2203-008242	C5031,C5033,C6008	C-CERAMIC,CHIP
2203-008242	C7148	C-CERAMIC,CHIP
2203-008654	C5111	C-CERAMIC,CHIP
2203-008749	C7002	C-CERAMIC,CHIP
2203-008860	C2090,C3006,C3009	C-CERAMIC,CHIP
2203-008860	C3032,C3041,C3055	C-CERAMIC,CHIP
2203-008860	C3080,C5174,C6012	C-CERAMIC,CHIP
2203-008860	C6034,C7015,C7016	C-CERAMIC,CHIP
2203-008860	C7020,C7032,C7034	C-CERAMIC,CHIP
2203-008876	C1021,C1060,C1090	C-CERAMIC,CHIP
2203-008876	C1100,C3010,C5075	C-CERAMIC,CHIP
2203-008876	C5135,C6021	C-CERAMIC,CHIP
2203-009134	C3003	C-CERAMIC,CHIP
2203-009167	C3046,C3061	C-CERAMIC,CHIP
2203-009210	C7027	C-CERAMIC,CHIP
2203-009220	C3050	C-CERAMIC,CHIP
2203-009328	C4086,C5038,C5039	C-CERAMIC,CHIP
2203-009328	C5052,C5063	C-CERAMIC,CHIP
2203-009537	C5003	C-CERAMIC,CHIP
2203-009551	C7043,C7044	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-009618	C5044,C5069,C5070	C-CERAMIC,CHIP
2203-009618	C5175,C6006	C-CERAMIC,CHIP
2203-009733	C1041,C2006,C3024	C-CERAMIC,CHIP
2203-009733	C3043,C3053,C5037	C-CERAMIC,CHIP
2203-009733	C5040,C5043,C5048	C-CERAMIC,CHIP
2203-009733	C5049,C5050,C5054	C-CERAMIC,CHIP
2203-009733	C5055,C5059,C5062	C-CERAMIC,CHIP
2203-009733	C5065,C5066,C5071	C-CERAMIC,CHIP
2203-009733	C5076,C5081,C6011	C-CERAMIC,CHIP
2203-009733	C6018,C6031,C7009	C-CERAMIC,CHIP
2203-009733	C7010,C7026,C7029	C-CERAMIC,CHIP
2203-009733	C7030,C7036,C7038	C-CERAMIC,CHIP
2203-010085	C4060,C4061,C5041	C-CERAMIC,CHIP
2203-010085	C5047,C5060,C5074	C-CERAMIC,CHIP
2703-002309	L6002	INDUCTOR-SMD
2703-002900	L2021,L6000	INDUCTOR-SMD
2703-002953	L6001	INDUCTOR-SMD
2703-002959	L3013	INDUCTOR-SMD
2703-003476	L3000	INDUCTOR-SMD
2703-003970	L3015	INDUCTOR-SMD
2703-004012	C1046,C1065,C2003	INDUCTOR-SMD
2703-004012	L1057	INDUCTOR-SMD
2703-004013	C1036,C2031,C2056	INDUCTOR-SMD
2703-004013	L3014	INDUCTOR-SMD
2703-004014	C3070,L3020	INDUCTOR-SMD
2703-004032	C1024,C1051,L1002	INDUCTOR-SMD
2703-004032	L1035,L2011	INDUCTOR-SMD
2703-004033	C1013	INDUCTOR-SMD
2703-004034	C1086,C2002,L1004	INDUCTOR-SMD
2703-004034	L1053,L2020,L3002	INDUCTOR-SMD
2703-004034	L3010	INDUCTOR-SMD
2703-004035	C1010,C1012,L1005	INDUCTOR-SMD
2703-004035	L1014,L1016,L1056	INDUCTOR-SMD
2703-004035	L2027	INDUCTOR-SMD
2703-004036	C1093,C2018,L1019	INDUCTOR-SMD
2703-004036	L1021,L1030,L1034	INDUCTOR-SMD
2703-004036	L3009	INDUCTOR-SMD
2703-004037	C1057,C2033,C2074	INDUCTOR-SMD
2703-004037	L1011,L1015,L1022	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004037	L1032,L2023	INDUCTOR-SMD
2703-004038	C1032,C2030,L2012	INDUCTOR-SMD
2703-004171	L1000,L1039,L2006	INDUCTOR-SMD
2703-004171	L2018	INDUCTOR-SMD
2703-004328	C1080,C1088,C1092	INDUCTOR-SMD
2703-004328	C2026,C2038,L1024	INDUCTOR-SMD
2703-004328	L1036,L1047	INDUCTOR-SMD
2703-004366	C1098,L1018,L3005	INDUCTOR-SMD
2703-004367	C2004,L1029,L1043	INDUCTOR-SMD
2703-004367	L3007	INDUCTOR-SMD
2703-004368	L3003	INDUCTOR-SMD
2703-004763	L1001,L1007,L1008	INDUCTOR-SMD
2703-004764	C2013,L1017,L1020	INDUCTOR-SMD
2703-004764	L1026,L2000,L3016	INDUCTOR-SMD
2703-004862	C2069,L1033	INDUCTOR-SMD
2703-005058	C2014	INDUCTOR-SMD
2703-005066	L2005	INDUCTOR-SMD
2703-005098	L2019	INDUCTOR-SMD
2703-005116	L7006,U10927	INDUCTOR-SMD
2703-005118	L7005	INDUCTOR-SMD
2703-005201	L5001,L5003,L5004	INDUCTOR-SMD
2703-005201	L5005,L5010	INDUCTOR-SMD
2703-005366	C1034	INDUCTOR-SMD
2703-005555	L3011,L3012	INDUCTOR-SMD
2703-005689	L5000,L5006,L5007	INDUCTOR-SMD
2703-005689	L5008,L5009	INDUCTOR-SMD
2801-005264	OSC5000	CRYSTAL-UNIT
2802-001287	OSC3000	RESONATOR-CERAMIC
2805-001118	OSC2000	OSCILLATOR
2901-001690	C4027,C4057,C4058	FILTER-EMI
2901-001690	C4059,C4084,C4085	FILTER-EMI
2901-001690	U10990	FILTER-EMI
2904-002137	F1009,F2007	FILTER-SAW
2904-002150	F1008	FILTER-SAW
2904-002260	F1003	FILTER-SAW
2904-002266	F1011	FILTER-SAW
2904-002269	F1006,F2001	FILTER-SAW
2904-002335	F2002	FILTER-SAW
2904-002344	F2000	FILTER-SAW

5. MAIN Electrical Parts List

2904-002355	F3001,F3002	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002397	F1005	FILTER-SAW
2904-002405	F2004	FILTER-SAW
2910-000301	F1012	FILTER
2910-000342	F1007	FILTER
2910-000375	F1010	FILTER
2910-000385	F1001	FILTER
3003-001237	MIC6000	MIC-CONDENSOR
3301-001812	L7004	CORE-FERRITE
3301-001901	L7003	CORE-FERRITE
3301-002035	L6005	CORE-FERRITE
3301-002078	L6011,L6016,L6017	CORE-FERRITE
3301-002078	L6018,L6019,L6020	CORE-FERRITE
3301-002122	L2003,L2004,L6010	CORE-FERRITE
3301-002122	L6015,U10923	CORE-FERRITE
3301-002223	L7000,L7007,L7009	CORE-FERRITE
3301-002235	L6004,L6006,L6007	CORE-FERRITE
3301-002235	L6009,L6012,L6013	CORE-FERRITE
3301-002237	L2025,L2026,L7001	CORE-FERRITE
3301-002237	L7002	CORE-FERRITE
3301-002238	L3008,L3098	CORE-FERRITE
3301-002305	L6003,L6008	CORE-FERRITE
3301-002331	L5011	CORE-FERRITE
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001892	SIM6000	CONNECTOR-CARD
3710-003193	SOC7002	CONNECTOR-SOCKET
3710-004008	SOC5001	CONNECTOR-SOCKET
3710-004109	U10971	CONNECTOR-SOCKET
3710-004344	SOC5000	CONNECTOR-SOCKET
3711-008508	HDC7001	CONNECTOR-HEADER
3711-008511	HDC7002	CONNECTOR-HEADER
3711-008997	HEA6000	CONNECTOR-HEADER
3712-001604	ANT2008,ANT3000	CONNECTOR
3712-001626	ANT3001,ANT3002	CONNECTOR
3712-001633	ANT6006,ANT6007	CONNECTOR
3712-001694	ANT2001,ANT2004	CONNECTOR
3712-001694	ANT2005,ANT2006	CONNECTOR
3712-001694	ANT2007,ANT2009	CONNECTOR

5. MAIN Electrical Parts List

3712-001694	ANT2010,ANT3004	CONNECTOR
3712-001694	ANT3005,ANT6000	CONNECTOR
3712-001694	ANT6001	CONNECTOR
3712-001731	ANT2002,ANT2003	CONNECTOR
4709-002226	F2005	RF-MODULE
4709-002284	F3003	RF-MODULE
4709-002416	F1000	RF-MODULE
4709-002589	F1004	RF-MODULE
GH02-19230A	SC6001SP	SHIELDCAN TAPE
GH62-00042A	GA7000	GASKET
GH63-16268A	SC6008	SHIELDCAN
GH63-17820A	SC6001	SHIELDCAN
GH63-17822A	SC6002	SHIELDCAN
GH63-17823A	SC6003	SHIELDCAN
GH98-44631A	SC6000	SHIELDCAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.